


Chassis Quick Reference




Front Panel Controls and Indicators

- A. HDD Tray Activity LED
- B. USB 2.0 Port
- C. LAN1 & LAN2 LED
- D. Alarm Mute Button
- E. System Reset Button F. Failure LED
- G. System HDD Activity LED
- H. Power LED
- I. Power Button






Top Cover Opening



▲ CAUTION ▲


This unit must be operated with the chassis TOP COVER installed to ensure proper cooling

Installing Hard Drive




- 1. Insert the hard drive on the tray.
- 2. Attach with four screws to fix HDD.
- 3. Slide tray into chassis.
- 4. Push the lever to latch HDD tray.

Moving Hot Swappable Fan Module




1. Moving the latch until hook releasing 2. Pull up fan module then fan board disconnecting.

Moving Power Supply Cage Module



- Disconnectina all cables before taking out cage module.
- 2. Releasing 9 pcs screws for cage then taking out.
- 3. Releasing 16 pcs screws for power supply.

Moving Main Board Cage Module




- 1. Pulling out all fan modules before taking out cage module.
- 2. Disconnecting all cables before taking out cage module.
- 3. Releasing 10 pcs screws for cage then taking out.

Installing Slim HDD & Slim FDD

back and take out bracket.

1. Release screw then move 2. Attach with two screws for slim CD-ROM adapter.

3. Attach with two screws for slim FDD adapter.











5. Fit to three gauge pins and move forward until fasten.

6. Attach back original screw


Installing Internal HDD & FDD

- 1. Release screw then move back and take out bracket
- 2. Attach with four screws to fit HDD/FDD
- 3. Fit to two gauge pins and move forward until fasten
- 4. Attach back original screw









FDD






5. Repeat step 1~4 for 2nd backplame

assembly and placement

Installing Backplane Assembly

- 1. Attach with 6 stand-offs on bracket location with "S" mark.
- 2. Attach with 4 screws for each backplane assembly.
- 3. Place backplane assembly along internal backplane guide rail.
- 4. Attach with 3 screws on both sides of chassis.



74-123519-002 2005.11