



# Chassis Quick Reference

## Major Components




## Front Panel Controls and Indicators


- |                        |                     |                    |
|------------------------|---------------------|--------------------|
| A. USB Port            | D. HDD Activity LED | G. LAN1 & LAN2 LED |
| B. System Reset Button | E. Power LED        | H. Power Switch    |
| C. Alarm Mute Button   | F. Failure LED      |                    |




## Rear Window Configuration




## Top Cover Opening




## Installing Hard Drive




## Installing CD-ROM



## Installing PCI Riser Card



## Installing Fan Module & Power Supply



## Installing Backplane Assembly

